INSTALLATION GUIDELINES





ATTENTION

- There is potential danger of electrical shock when operating electrical components.
- Make sure power is turned off before installation.
- Allow for heat dissipation and adequate ventilation

BL Lighting does not provide structural tension cables, cable ends, mounting fittings, or structural masts/poles required for catenary lighting installations. The design, engineering, and installation of all catenary systems must be reviewed and approved by a licensed structural engineer to ensure structural integrity and compliance with site-specific conditions, including luminaire weight, applied load, span, and environmental factors such as wind, ice, and corrosion.

By using BL Lighting's catenary products, the installer assumes responsibility for ensuring all necessary engineering assessments and approvals are in place.

Lighting Fixtures

Zephyr ZC6314 - Slim Lens

Size: 2.48" x 2.48" x 5.47" (63mm x 63mm x 139mm) Weight: 1.21 lbs (550g)

Please note that these instructions are guidelines only and in no way supersede any construction or installation standards.

Local building and electrical codes should be consulted before installation



Zephyr ZC6323 - Slim Lens

Size: 2.48" x 2.48" x 9.06"

Weight: 1.70 lbs (770g)

(63mm x 63mm x 230mm)

Zephyr ZC6314 - Standard Lens

Size: 2.48″ x 2.48″ x 5.70″ (63mm x 63mm x 145mm) Weight: 1.21 lbs (550g)



Zephyr ZC6323 - Standard Lens

Size: 2.48" x 2.48" x 9.65" (63mm x 63mm x 245mm) Weight: 1.70 lbs (770g)



BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Designed & Assembled in North America.

For more information please download the BL LIGHTING catalog



Specifications subject to change without notice. Please refer to our website at bliighting.com for current technical data.

bllighting.com

Zephyr BL Catenary



Isometric

The length of **"B" Power + Connector** varies depending on the spacing between the lights.



For ZC6314 (550g per unit),

- With 5W units, up to 18 lights can be installed in a *single run
- With 10W units, up to 9 lights can be installed in a *single run

For ZC6323 (770g per unit),

• With 2x5W units, up to 9 lights can be installed in a *single run



BL LIGHTING ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Designed & Assembled in North America.

For more information please download the BL LIGHTING catalog

bllighting.com



Specifications subject to change without notice. Please refer to our website at bllighting.com for current technical data.



Fixing the Power Cable to the Aircraft Cable





1. Cotton Friction Tape

Before securing the power cable to the aircraft cable with a cable tie, wrap cotton friction tape around the aircraft cable at the location where the cable tie will be fastened to prevent damage to the power cable.

2. UV Cable Tie

Please secure a UV cable tie at the end of each connector and then tie them at 2-foot intervals along the length.

Recommended Maximum Installation Height



BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Desianed & Assembled in North America.







To install **Zephyr** on aircraft cable, follow the steps below.



2.

Use a 5/32"(4mm) hex key to turn the hex bolt on the **Zephyr** cover counterclockwise to open the cover.



2-1.

Please note that you do not need to turn the hex bolt all the way to remove it.

There is an O-ring on the lower part of the cover, so be careful not to let the O-ring come off the hex bolt.

BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8
P: 1-604-874-4405 E: info@bllighting.com
Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved.

Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Besigned & Assembled in North America.





Specifications subject to change without notice. Please refer to our website at blighting.com for current technical data.





After opening the cover of **Zephyr**, you will see a mounting clamp with two hex bolts. Loosen the bolts on this mounting clamp to prepare for inserting the aircraft cable inside.





4.

Using a hex key, turn it counterclockwise to loosen the hex bolts. Depending on the thickness of the aircraft cable that will be inserted and secured inside this mounting clamp, determine how much to loosen them hex bolts.

If the aircraft cable thickness is 1/8" (3.2mm) or less, you can install the aircraft cable by inserting it without fully loosening the hex bolts.

However, if the aircraft cable is thicker than 1/8" (3.2mm), you need to completely loosen the hex bolts, remove the mounting clamp entirely, insert the aircraft cable, and then reattach the mounting clamp. The maximum allowable aircraft cable diameter for installation is 15/64" (6mm).

5.

The mounting clamp on the **Zephyr** allows for adjustment of the fixture's orientation to the left or right along its direction, depending on how you secure the aircraft cable.

After aligning the fixture to the desired angle to accommodate swag, tighten the hex bolts by turning them counterclockwise"

BL LIGHTING ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Desianed & Assembled in North America.



Specifications subject to change without notice. Please refer to our website at bllighting.com for current technical data.





After securing the **Zephyr** to the aircraft cable, close the **Zephyr** cover by turning it clockwise with a hex key to fix it to the **Zephyr** body. When tightening, make sure the O-ring is not dislodged.

Connector Termination Procedure

	1

1.

Lay out all components of the **Zephyr** connector

BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Designed & Assembled in North America.

For more information, please download the BL LIGHTING catalog



Specifications subject to change without notice. Please refer to our website at bllighting.com for current technical data.





Carefully remove 1" (25.4 mm) of the outer cable jacket from the top end.



3.

Strip each conductor to expose 0.5" (12.7 mm) of the inner copper wire.



4.

Place the cable gland over the prepared cable.

NOTE:

Before connecting the conductors, add dielectric grease to the conductors and the ports to prevent corrosion.

BL LIGHTING ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Designed & Assembled in North America.

bllighting.com







Insert the conducts and festen the locking screws L = white wire 24VDC+ N = black wire 24VDC-



6.

Slide the cable gland back up into position and tighten it both side.



7.

Finalize the assembly by locking any external nuts.

BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty. Designed & Assembled in North America.



Specifications subject to change without notice. Please refer to our website at blighting.com for current technical data.





DONE

BL LIGHTING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty.

Designed & Assembled in North America.

L

Specifications subject to change without notice. Please refer to our website at blighting.com for current technical data.

For more information, please download the BL LIGHTING catalog

bllighting.com

