

*All devices in a DMX512 system must be connected in a "daisy chain" fashion.

ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved.


Specifications subject to change without notice. Please refer to our website at bllighting.com for current technical data.

For more information, please download the BL LIGHTING catalog
















ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. Solid State Lighting is sensitive to power fluctuations. Surge protection is highly recommended for all LED lighting products and should be on a dedicated circuit to protect against premature failure. Lack of surge protection may void your warranty.

Designed & Assembled in North America.


Specifications subject to change without notice. Please refer to our website at bllighting.com for current technical data.












*All devices in a DMX512 system must be connected in a "daisy chain" fashion.

ILLUMINATE EVERYTHING

111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved.








bllighting.com









BL LIGHTING FIXTURE Main Power Supply (Input) 4CH(RGBW) **BL LED Driver** Decoder RDM SP UNI 92525 From Previous DMX IN Decoder RDM DMX In/out 占占占 回


*Ground wires(GND) must loop to each decoder



111 - 8838 Heather St. Vancouver, BC. Canada. V6P 3S8 P: 1-604-874-4405 E: info@bllighting.com Copyright © BL INNOVATIVE LIGHTING. All Rights Reserved. *Last RDM decoder needs a Resistor







After each 10 decoders, an amplifier should be added to the daisy chain to maintain DMX signal quality.

ILLUMINATE EVERYTHING

