



\*All devices in a DMX512 system must be connected in a "daisy chain" fashion.

















\*All devices in a DMX512 system must be connected in a "daisy chain" fashion.










ILLUMINATE EVERYTHING






\*Ground wires(GND) must loop to each decoder














After each 10 decoders, an amplifier should be added to the daisy chain to maintain DMX signal quality.

ILLUMINATE EVERYTHING

bllighting.com