BL areaCIRCULAR CR 197

Circular LED Wall Washer 24W, 100-277VAC Line Voltage

INSTALLATION INSTRUCTIONS






Please note that these instructions are guidelines only and in no way supersede any construction or installation standards.

ocal building and electrical codes should be consulted before installation.

ATTENTION


- There is potential danger of electrical shock when operating electrical components.
- Make sure power is turned off before installation.
- Allow for heat dissipation and adequate ventilation.

SURFACE MOUNT
Mountable base with 180° Adjustable Bracket



1.

A. Position **CR197** at desired location of install. B. Fasten mounting bracket with bolts through mounting holes.



2.

Loosen screws with Hex Key.

ILLUMINATE EVERYTHING



BL areaCIRCULAR CR 197

Circular LED Wall Washer 24W, 100-277VAC Line Voltage

INSTALLATION INSTRUCTIONS






Please note that these instructions are guidelines only and in no way supersede any construction or installation standards.

ocal building and electrical codes should be consulted before installation

ATTENTION


- There is potential danger of electrical shock when operating electrical components.
- Make sure power is turned off before installation.
- Allow for heat dissipation and adequate ventilation.

SURFACE MOUNT Mountable base with 180° Adjustable Bracket



3.

Tilt CR197 at desired angle.



4.

Re-Tighten with Hex Key.

