


1. Lights Control

A. To control your lights with the BT C8 controller please download the Casambi App available for Android (Google Play)and IOS (App Store) and follow the instructions on the manual attached.

2. Wiring Diagram



* The relay must be protected against inductive over voltage spikes, i.e. it must have a flyback diode. Do not connect a typical PCB relay without the diode.
RELAY and SENSOR outputs are optional.

