



**CONNECTIONS**  
Power and 0-10V 4 Pins



- 1** 4 Pin Female Connector
- 2** 4 Pin Male Connector

- 1** Pin 1 : 0-10V -
- 2** Pin 2 : n.c.
- 3** Pin 3 : n.c.
- 4** Pin 4 : 0-10V +



**4 Pin Female Connector**  
• To Master Controller  
• To Previous CR247

